

CITIZEN

IF1-EFX1 / IF1-EFX2 / IF1-EFX3 IF2-EFX1 / IF2-EFX2 / IF2-EFX3 Ethernet Interface Board User's Manual

Ver.2.10

Target firmware V1.15 or later (IFx-EFX1), V2.30 or later (IFx-EFX2), V2.33 or later (IFx-EFX3)

CITIZEN SYSTEMS JAPAN CO., LTD.

Contents

Contents	2
Read before using	4
1. Introduction	7
1-1. Features	7
1-2. Model Classification	8
1-3. Specifications	8
1-4. Part Names and Functions	10
2. Preparation	11
2-1. Connecting LAN cable.....	11
2-2. Connecting a Peripheral Device	11
2-3. Connecting the Interface Board Unit	12
3. Network Settings and Operation.....	14
3-1. Overview	14
3-2. Panel Button.....	16
3-3. Printing the Interface Board Configuration.....	17
3-4. Returning the Interface Board Configuration to Factory Default Settings.....	18
3-5. Display status by LED	19
3-6. Simple Setting Procedure Example for Wired LAN	20
4. Web Manager	21
4-1. Starting the Web Manager	21
4-2. HOME Window.....	22
4-3. STATUS Window	23
4-3-1. STATUS>>System Status Tab	24
4-3-2. STATUS>>Network Status Tab	25
4-3-3. STATUS>>Printer Status Tab.....	26
4-4. CONFIG Window.....	27
4-4-1. CONFIG>>General Tab	28
4-4-2. CONFIG>>User Account Tab	29
4-4-3. CONFIG>>Maintenance Tab	30
5. NetToolK.....	31
5-1. Installing the NetToolK	31
5-2. Information List Window.....	34
5-3. Setup Window.....	36
5-3-1. “General” Tab.....	36
5-3-2. “Wireless LAN” Tab.....	36
5-3-3. “Supported Protocols” Tab	37
5-3-4. “User Account” Tab.....	37
5-3-5. “Maintenance” Tab	37
6. XML Print / Peripheral Device Control Function.....	39
6-1. Overview	39
6-2. CONFIG>>Service Tab	40

6-2-1.	Media Converter.....	41
6-2-2.	XML Print.....	41
6-2-3.	XML Device Control.....	41
6-2-4.	XML Device Control / Line Display	42
6-2-5.	XML Device Control / Scanner	42
6-2-6.	XML Device Control / Speaker	42
6-2-7.	XML Config.....	42
6-2-8.	Submit / Reset Button.....	42
6-3.	STATUS>>Service Status Tab.....	43
7.	SSL/TLS function	44
7-1.	Overview	44
7-2.	CONFIG>>SSL/TLS Tab	46
7-2-1.	SSL/TLS tab	46
7-2-2.	Create Self-Signed Certificate.....	47
7-2-3.	Update Self-Signed Certificate.....	48
7-3.	To enable SSL/TLS communication using a self-signed certificate	49
7-3-1.	Generating and exporting self-signed certificates	49
7-3-2.	Example of importing a self-signed certificate in a browser (Chrome)	54
7-4.	SSL/TLS and certificate related specifications	58
7-4-1.	SSL/TLS communication specifications.....	58
7-4-2.	Self-signed certificate related specifications	59
7-4-3.	CA signed certificate related specifications.....	60
7-4-4.	Handling of saved certificates when restoring factory settings/updating firmware	60
8.	Request Print function	61
8-1.	Overview	61
8-2.	CONFIG>>Request Print Tab.....	62
8-3.	STATUS>>Request Print Tab	63
8-4.	Printing system log	63

Read before using

Be sure to read this manual carefully before using the product. After you read it, store it in a safe place so that you can reread it when necessary.

- Contents of this manual may be changed without notice.
- Reproducing and/or copying the contents of this manual by any means without permission are prohibited.
- We will not be responsible for any adverse occurrence that results from the use of this manual, regardless if it contains omissions, errors/misprints, etc.
- Note that we will not be responsible for (a) loss caused by improper operation or mishandling of the device by the user, or (b) loss due to operational environment.
- Data etc. are basically impermanent; long time or permanent storing/saving of data by the device is not possible.
- Note that we will not be responsible for any loss or loss of profits owing to loss of data due to breakdown, repairs, inspections, etc.
- Please contact us if there are omissions, errors, ambiguities, etc. in this manual.
- Refer to this document along with the user manual of the printer.

Trademarks

- Microsoft, Windows 7, Windows 8, Windows 10 and Windows 11 are registered trademarks of Microsoft Corporation U.S.A.
- CITIZEN is a registered trademark of Citizen Watch Co., Ltd.
- Other company names and product names mentioned here are trademarks or registered trademarks of those companies.

Related SDKs and Documentation

Printing with XML data

- * XML Print (For POS printers)
 - POS Print SDK(JavaScript)
 - CITIZEN XML Print Service JavaScript POS Print SDK Programming Manual
- * XML Print (For Label printers)
 - Label Print SDK(JavaScript)
 - CITIZEN XML Print Service JavaScript Label Print SDK Programming Manual

Network board configuration with XML data

- * XML Config (JavaScript)
 - Config SDK(JavaScript)
 - CITIZEN XML Device Control Service JavaScript Device Control SDK Programming Manual

Peripheral device control using XML data

- * XML Device 【JavaScript】
 - Device Control SDK (JavaScript)
 - CITIZEN XML Config Service JavaScript Config SDK Programming Manual

Peripheral device control using dedicated control port

- * Peripheral device control (For POS printer / Windows)
 - POS Print SDK (Windows)
 - Windows POS Print SDK Programming Manual
- * Peripheral device control (For POS printer / Android)
 - POS Print SDK (Android)
 - Android POS Print SDK Programming Manual
- * Peripheral device control (For POS printer /iOS-Swift)
 - POS Print SDK (iOS-Swift)
 - iOS POS Print SDK (Swift) Programing Manual
- * Peripheral device control (For POS printer / iOS Objective C)
 - POS Print SDK (iOS-Objective C)
 - iOS POS Print SDK (Objective-C) Programing Manual

(Peripheral device control from the label printer can also be performed using the SDK for POS printers.)

Request printing

- Programmer's Manual for "Request Print" on XML Print Service (Sample program)

Term Description

Since different documents are intended for different audiences and assume different levels of expertise, different terms may be applied for clarity even when the content being explained is the same. In addition, some terms are easily confused because they are sometimes referred to from the opposite standpoint depending on their function. The following is a glossary and explanation of terms that you should pay attention to when reading this document in conjunction with other related documents.

Printer / Interface board (Wired or Wireless LAN) / Service

Printers that use network and XML related functions have an interface board (wired/wireless LAN) that is a single board computer. On the memory on that interface board, there are several resident programs that perform specific functions, which are called services.

For example, the XML Print service receives XML data for printing, converts it into commands and data for the printer, passes it to the printer, and sends a reply when it is confirmed that the printing is completed. From the point of view of the terminal sending the data, it is easier to recognize network and XML-related services as interface boards or printers, so we may use the terms "board," "interface board," or "printer" instead of "service" in the explanation.

Web server / Web app server

The Web server is the terminal that sends data to the browser for screen display. The Web server receives the information of the operations performed on the browser. When a Web server uses a programming language to process data to be sent and received, the group of programs that process the data is called a Web application (hereinafter referred to as a Web app), and the terminal in charge of the function is called a Web app server.

Since there are many cases where a Web server and a Web app server are both used on the same terminal, the two are not strictly separated and may be referred to as a Web server in the sense of a Web app server.

Server / Client

In addition to Web server and Web app sever, there are various other types of servers depending on their functions, which are sometimes referred to simply as servers in the explanation.

The terminal that sends data to the server is called the client. Server and client are sometimes referred to interchangeably, depending on their function and position.

For example, in the main function of the printer, which is to print the received data, the printer is a print server from the terminal that sends the print data to the printer. The printer also has the function of a Web server, which we call a Web manager, for network settings, etc.

On the other hand, when sending a print data request to the Web app server, the printer is in the position of a client.

1. Introduction

Thank you for purchasing the Citizen IF1-EFX1/EFX2/EFX3, IF2-EFX1/EFX2/EFX3 Ethernet (LAN) interface board.

By using the LAN interface board IF1-EFX1/EFX2/EFX3, IF2-EFX1/EFX2/EFX3 (hereinafter referred to as the interface board, this interface board or this board) with our POS printers and barcode printers, each printer can be directly connected to the network enabling printing from a PC on the network to the printer. It also enables the PC and printer to communicate with each other, and the printer's operating status and print settings can be checked from the PC. In addition, depending on the printer, it is possible to print from XML format data and control peripheral devices connected to this interface board.

Please note only firmware versions

V1.15 or later (IFx-EFX1)

V2.30 or later (IFx-EFX2).

V2.33 or later (IFx-EFX3)

support the following functions mentioned in this manual.

Raw Port TCP Keep-Alive

SSL/TLS Function (IFx-EFX2/EFX3 only)

Request Printing (IFx-EFX2 only)

XML Config

For boards with older firmware versions, please refer to the older manual as a reference.

1-1. Features

- Support for DHCP, static IP, and ZeroConf methods of IP address acquisition
- Configuration through a browser or utility software
- Support for Raw 9100 port and LPR printing methods
- Panel button to print configuration information and change the configuration mode
- LED indicators for connection, operation, and error statuses
- Support for printing and peripheral device control by XML data depending on the printer
- Secure communication with SSL/TLS function. (IFx-EFX2/EFX3 only)
- "Request Print" allows printing with XML data from a Web server on the Internet (IFx-EFX2 only)
- XML Config function is available for configuration of the board.

2 Introduction

1-2. Model Classification

IF1 type: Applicable to CT-S801(II) / 851(II) / 601(II) / 851(II) / CL-S400DT / 6621 / CL-E7xx

IF2 type: Applicable to CT-D151 / CT-E601 / CT-E651 / CT-S251 / 751 / 4500 / CL-E3xxEX

	IF1 type			IF2 type		
	Normal model		USB host model	Normal model		USB host model
Name	IF1-EFX1	IF1-EFX3	IF1-EFX2	IF2-EFX1	IF2-EFX3	IF2-EFX2
Number of USB ports	0	0	2	0	0	2
Peripheral device control	Not supported	Not supported	Supported	Not supported	Not supported	Supported
SSL/TLS	Not supported	Supported	Supported	Not supported	Supported	Supported
Request print	Not supported	Not supported	Supported	Not supported	Not supported	Supported

1-3. Specifications

Main board (Network)

Ethernet	Standards	100BASE-TX/10BASE-T, Full Duplex/Half Duplex auto negotiation
	Port	RJ-45
Network	IP Version	IPv4
	Protocols	TCP, UDP, HTTP, HTTPS, ICMP, DHCP, SNMP
	Port number for printing	RAW (port 9100 (Changeable)), LPR
	IP address setting	Manual, DHCP

Hardware


		IF1-EFX1 / IF1-EFX2 / IF1-EFX3	IF2-EFX1 / IF2-EFX2 / IF2-EFX3
Hardware	Compatible printers	CT-S801(II) / 851(II) / 601(II) / 651(II) / CL-S400DT / 6621 / E7xx	CT-D151/E601/E651/S251 / CT-S751/4500/CL-E3xxEX
	Operation panel	LED: 4 (2 on panel, 2 on RJ45 connector), Button: 1	
	USB	USB-A connector 0 or 2 USB Specs: USB2.0 High Speed	

Software


Software	Setting methods	Browser, PC setting tool, Cloud
	Firmware upgrade	Browser, PC setting tool, Cloud
	Supported Platforms	Windows 7、Windows8, Windows10, Windows11, HTML5 browser

1-4. Part Names and Functions


IF1-EFX1 / IF1-EFX3 (No USB Port)




IF1-EFX2 (USB 2 Port)



IF2-EFX1 / IF2-EFX3 (No USB Port)



IF2-EFX2 (USB 2 Port)



- ① RJ45 connector (compatible with 10Base-T/100Base-TX)
Connection for LAN cable
- ② Ethernet transmission speed LED indicator (green)*1
Shows Ethernet transmission speed with steady/blinking light.
- ③ Ethernet status indicator LED (yellow)*1
Shows Ethernet connection status (disconnected, receiving data, etc.).
- ④ Ethernet status LED indicator (green)*1
- ⑤ Ethernet status LED indicator (red)*1
Shows transmission, connection and error statuses with steady/blinking lights combinations.
- ⑥ Panel button*2
Used to operate the Interface board.
- ⑦ USB connector (First)
- ⑧ USB connector (Second)
Connect an approved peripheral device to a USB port.


*1 See 3-5, Display status by LED (page 19) for indicator details.

*2 See 3-2, Panel Button (page 16) for panel button operations.

2. Preparation

2-1. Connecting LAN cable

Connect a LAN cable to the RJ45 connector of this interface board. (Diagram on right shows a typical example)



2-2. Connecting a Peripheral Device

The following restrictions apply to peripheral devices. Please use them properly.


- The connection of unsupported peripherals to the USB port is prohibited. (please inquire about which devices are supported).
- Connecting a tablet or other device to USB ports for supplying power is also prohibited.
- Do not insert or remove peripheral devices from the USB port while the printer power is on.
- Connection through a USB hub is prohibited.
- In the case of the IFx-EFX2 which has two USB ports, connecting to both the left and right ports is possible, but connecting two of the same type of device (two displays, two scanners, etc.) is prohibited.

2 Preparation

2-3. Connecting the Interface Board Unit

1) The interface board can be used by connecting it to the main board of the printer.


It is connected by plugging the printer interface connector into the connector on the printer's main board. It is possible to replace the other interface with the LAN interface, but extra caution is required. (Diagram below shows a typical example)




Warning

- Malfunctions may occur if the interface board is removed or re-inserted.
- To install the interface board, please contact your dealer or service person.
- If you replace the interface board by yourself, do so at your own risk, taking care to avoid static electricity, etc.


2) If another interface board is installed in the printer, remove it.




- 3) Insert the interface board into the interface slot of the printer.



- 4) Connect the interface connector of the board to the interface connector inside the printer.



- 5) Fix the interface board in place with screws.



3. Network Settings and Operation

3-1. Overview

To use this interface board connected to a network, you need to connect to the network and configure the settings for communication in addition to configuring the settings of the printer.

There are 3 methods to configure the settings for a network connection.


Web Manager

Connect to this interface board from a browser and then configure the settings on the dedicated settings screen.



NetToolK

Connect to this interface board from a dedicated tool for Windows and then configure the settings.



You can check the current state and restore the initial state by operating the panel button.

See the next captor for an explanation of the panel button.

Furthermore, you can check the communication and other statuses from the LEDs on the interface. See "3-5 Display status by LED".

XML Config

By sending XML format data to this interface board, you can configure some of the board's functions.

The functions that can be configured or updated are

- SSL/TLS settings

- Request printing settings

- Firmware update

Details are beyond the scope of this manual. Therefore, please refer to the manual of XML Config SDK for details.

JavaScript and Excel VBA macros are available as sample programs for this function.

The timeout setting for this function is present in the 6-2 CONFIG>>Service Tab.

Warning


After the firmware upgrade starts, do not disconnect power or transmission to the printer until the upgrade is complete.

When updating the firmware, it is necessary to obtain the correct firmware data from us.

If the firmware is not updated correctly, this interface board may not boot.

3-2. Panel Button

The panel button on the operation panel is used to operate the Interface board. It allows you to print the setting information of this interface board and restore the initial state. (Diagram is of IF1-EFX1 / IF1-EFX3 and IF1-EFX2)



■ Starting the Interface Board

Turn on the printer. The Interface board starts working approximately 20 seconds after the printer turns on.

■ Printing the Interface Board Configuration

Press the panel button. See 3-3, Printing the Interface Board Configuration (page 17) for details.

■ Switching to Setting Mode

Press and hold the panel button. The buzzer* will sound once, signaling a switch to setting mode.

- Setting mode enables the reading of the factory default settings. See 3-4, Returning the Interface Board Configuration to Factory Default Settings (page 18) for details
- If there is no activity for three seconds in the setting mode, the buzzer* will sound once, signaling a return to normal mode.

* If the printer to which this interface board is connected is set to not buzz, the buzzer will not sound.

Warning

When the operation is complete, the interface board will restart automatically.
When automatically obtaining the IP address from the DHCP server is set, an IP address that differs from the previous one may be assigned.

■ System log printing

If printing etc. does not work as expected, you may be able to check the situation by checking the system log of this board. The system log can be printed using the panel buttons.

Please refer to Chapter 5 "Useful Functions for Request Print" in the "Programmer's Manual for "Request Print" for a description of system log printing.

3-3. Printing the Interface Board Configuration


Press the panel button to print out the configuration of the interface board from the printer.

- ① Title of the printout.
- ② Model name, hardware revision, and firmware version of the interface board
- ③ System information of the interface board
The LAN board name, serial number, and MAC address are printed.
- ④ Network information of the interface board
- ⑤ Ethernet information. Printed when connected by Ethernet.
- ⑥ Printer information. The name of the manufacturer and the model name of the printer connected to the interface board are printed.
- ⑦ Configuration information of the interface board. The information stored in the interface board is printed and may be different from the connection status of the current network. Check the connection status using the network information of ④
- ⑧ Information on the connection status of XML-controlled peripheral devices.
- ⑨ SSL/TLS function setting information.
- ⑩ Setting information for the Request Print function.

①	I/F Board Information
②	IFx-EFX1(Rev1.1.2): Ver 1.15
③	System LAN Board Name : Net Printer Serial Number : 100123 MAC Address : 00:01:02:0a:0b:0c
④	Current Network Status IP Address : 192.168.0.2 (DHCP) Subnet Mask : 255.255.255.0 Gateway : 192.168.0.1 DHCP Server : 192.168.0.1
⑤	Ethernet Status Speed & Duplex : Auto (100BaseTx Full)
⑥	Printer Status Manufacturer : CITIZEN Model : CT-S801
⑦	User Configuration DHCP : Enable IP Address : 192.168.0.10 Subnet Mask : 255.255.255.0 Gateway : 192.168.0.1 Print Port : 9100 Receive Timeout : 180
⑧	XML Device Information Display Status : Offline Scanner Status : Offline Speaker Status : Offline
⑨	SSL/TLS Certificate : Self-Signed Self-Signed : Not Exist CA-Signed : Not Exist
⑩	Request Print Service Status : Disable Current URL : http://www.example.net/test.php Proxy Address : 192.168.100.190 Proxy Port : 8080 Interval : 10 sec ID : AA-BB-CC-DD-EE-FF DNS1 : 192.168.10.1 DNS2 : 8.8.8.8

3-4. Returning the Interface Board Configuration to Factory Default Settings

- 1) Press and hold the panel button to switch to setting mode.
- 2) After the interface board has switched to setting mode, press and holds the panel button again within three seconds. The following message is printed, and the interface board returns to factory default settings.



```
I/F Board
Information
--!Caution!--
Print Server will
automatically restart.
```


Warning

When the operation completes, this interface board restarts automatically.

When automatically obtaining the IP address from the DHCP server is set, an IP address that differs from the previous one may be assigned.

3-5. Display status by LED

(Diagram shows a typical example. There are interface boards where the positioning of LEDs differs, but the order from left to right is the same.)



① Ethernet transmission speed indicator

Transmission speed	LED (green)
100 Mbps	On
10 Mbps / Disconnected	Off

② Ethernet connection/transmission status indicator

Connection status	LED (yellow)
Connected	On
Disconnected	Off
Transmitting data	Flashing

③ LAN status indicator

Connection Status		LED (green)	LED (red)	Description
Printer disconnected		Off	-	Not connected to printer.
Printer connection	Network: disconnected	On	Off	Connected to printer.
	Ethernet connecting	On	Flashing (1-second cycle)	Seeking IP address from DHCP server via Ethernet.
	Ethernet working	On	On	Network operation via Ethernet.
Resource error		Alternating blinking (1-second cycle)		The interface board is malfunctioning.
System error		Alternating blinking (0.2-second cycle)		The interface board is malfunctioning.

3-6. Simple Setting Procedure Example for Wired LAN

If you do not know much about network settings, configure the settings about the corresponding procedure below.

However, the instructions in the procedure may not necessarily be appropriate for your network environment.

■ Configuration where an IP address is assigned from a DHCP server

- 1) Connect the LAN cable to the interface board. The LAN cable must be connected to, for example, an enabled network environment in which a DHCP server exists.
- 2) The IP address is automatically obtained from the DHCP server within 90 seconds after powering on the printer and starting up this interface board.

Press the panel button to print out the configuration information and check the assigned IP address. See 3-3, Printing the Interface Board Configuration (page 17) for details.

- 3) Once the conditions for the printer to join the network are in place, configure the wired LAN settings in Web Manager.

Connect to Web Manager of the printer from the browser of a PC connected to the same network. See "4 Web Manager" (page 21) for details.

Instead of Web Manager, you can also use NetToolK, a network configuration tool for Windows. See "5 NetToolK" (page 31) for details.

■ Configuration using a static IP address

The procedure differs for the part of step 2) above. Since the IP address assigned by the DHCP server is not used, the ZeroConf function assigns an IP address of 169.254.XX.YY (XX.YY varies depending on the environment). Press the panel button to print the setting information and then confirm the assigned IP address.

Adjust the IP address of your PC so that it can connect to the IP address of the printer.

The subsequent procedure is the same as step 3) above.


4. Web Manager

The interface board is equipped with a Web manager function, which allows accessing the interface board from a Web browser to check the status of the interface board and change its settings.

4-1. Starting the Web Manager

In the address bar, enter the IP address and then press **Enter**.

If the SSL/TLS feature is enabled, you can also connect using "https".




* The image to the left is a sample. Enter the actual allocated value for the IP address.

Warning

- The configuration window of the interface board cannot be displayed if the network settings of your computer and the interface board differ. Ensure that the IP address of the interface board matches the settings of your network.
- The IP address of this interface can be confirmed as described in "Printing the Interface Board Configuration".

Web Manager Window Layout

Web Manager consists of following windows and tabs. It differs depending on supported functions.



*1 If the XML/Peripheral control functions are available, the Service Status tab will appear on the STATUS windows and the Service tab will appear on the CONFIG windows.


*2 If the SSL/TLS function is available, the SSL/TLS tab will appear in the CONFIG window.

*3 If Request Print function is available, Request Print tab will appear on STATUS / CONFIG window.

For details, see "6 XML Print / Peripheral Device Control Function," "7 SSL/TLS function," and "8 Request Print function," respectively.

4-2. HOME Window


This is the Home window of the Web manager.



- ① HOME button
Display the Home window.
- ② STATUS button
Display the Status window. At the status window, you can check the status of the Interface board.
- ③ CONFIG button
Display the CONFIG window. At the CONFIG window, you can configure the Interface board.
- ④ Logout button
Log out from the CONFIG window of the Interface board. It is not possible to open the CONFIG window at multiple PCs of the same time. You must log out to make settings using another Web manager or NetToolK.


4-3. STATUS Window

Displays the status of the Interface board.



- ① System Status tab
See 4-3-1, STATUS>>System Status Tab (page 24).
- ② Network Status tab
See 4-3-2, STATUS>>Network Status Tab (page 25).
- ③ Printer Status tab
See 4-3-3, STATUS>>Printer Status Tab (page 26).
- ④ Service Status tab
See 6-3 STATUS>>Service Status Tab (page 43)
- ⑤ Request Print tab
See 8-3 STATUS>>Request Print Tab (page 63)

4-3-1. STATUS>>System Status Tab




- ① Firmware Version
Displays the firmware version of the Interface board.
- ② Model Name
Displays the model name of the Interface board.
- ③ Serial Number
Displays the serial number of the Interface board.
- ④ MAC Address
Displays the MAC address of the Interface board.
- ⑤ RAW Port Number
Displays the TCP port number for RAW printing.
- ⑥ Timeout for print data
Displays the socket timeout duration during printing. When the host and the TCP/IP socket are connected, and the host sends no data for this duration during printing, the socket is forced to close. When the setting is "0", the socket remains connected until a disconnection request is received from the host.
- ⑦ LPR Queue Name
Displays the LPR queue name.
- ⑧ UPnP
Displays the UPnP configuration status.

4-3-2. STATUS>>Network Status Tab

System Status	Network Status	Printer Status
LAN board name:	Net Printer	①
IP Address:	192.168.1.101 (dhcp)	②
Subnet Mask:	255.255.255.0	③ ④
Default Gateway:	192.168.1.1	⑤
DHCP Server:	192.168.1.1	⑥
Lease Time:	86400 seconds	⑦
SSL/TLS:	Self-Signed	⑧
Self-Signed:	Exist	⑨
CA-Signed:	Exist	⑨

- ① LAN board name
displays the LAN board name of the Interface board.
- ② IP Address
Displays the IP address of the Interface board.
- ③ Subnet Mask
displays the subnet mask of the Interface board.
- ④ Default Gateway
displays the default gateway of the Interface board.
- ⑤ DHCP Server
Displays the IP address of the DHCP server from which the Interface board obtained its IP address.
- ⑥ Lease Time
Displays the lease time of the IP address allocated by the DHCP server.
- ⑦ SSL/TLS
Displays the status of SSL/TLS function
 - Disable: The function is disabled.
 - Self-Singed: The function is enabled by the self-signed certificate.
 - CA-Signed: The function is enabled by the certificate authenticated by CA
- ⑧ Self-Signed
Displays the registration status of the self-signed certificate
- ⑨ CA-Signed
Displays the registration status of the certificate authenticated by CA

4-3-3. STATUS>>Printer Status Tab



- ① Manufacturer
Displays "CITIZEN".
- ② Printer Model
Displays the model of the printer to which the Interface board is connected.
- ③ Printer Status
Displays the operational status of the printer to which the Interface board is connected.
Ready: Ready to print.
Offline: Not ready to print.
Paper Empty: Out of paper.
Error: Error status.

(Note) When the printer is connected to the Interface board and the bi-directional port of the printer driver is enabled, the printer status is not correctly displayed. In such cases, confirm the printer status from the Windows spooler.

4-4. CONFIG Window

You can configure the Interface board after logging in as an administrator.

User Name / Password


Enter administrator user name and administrator password. (Initial setting: admin / admin)

Login button

Click "Login". The CONFIG window appears.

Cancel button

Cancel login.



- ① General tab
See 4-4-1 CONFIG>>General Tab (page 28).
- ② Service tab
See 6-2 CONFIG>>Service Tab (page 40)
- ③ SSL/TLS tab
See 7-2 CONFIG>>SSL/TLS Tab (page 46)
- ④ Request Print tab
See 8-2 CONFIG>>Request Print Tab (page 62)
- ⑤ User Account tab
See 4-4-2 CONFIG>>User Tab (page 29).
- ⑥ Maintenance tab
See 4-4-3 CONFIG>>Maintenance Tab (page 30).

4-4-1. CONFIG>>General Tab

The screenshot shows the 'General' tab of the CONFIG interface. It is divided into four sections: LAN board Information, TCP/IP, UPnP Setting, and Print Settings. The LAN board name is 'Net Printer'. Under TCP/IP, 'Obtain an IP Address Automatically' is selected, with IP Address, Subnet Mask, and Default Gateway all set to 192.168.10.100. Under UPnP Setting, 'Enable' is selected. Under Print Settings, Raw Port Number is 9100, Timeout for print data is 180 seconds, and 'Close all sessions' is selected for Action at Timeout. There are 'Submit' and 'Reset' buttons at the bottom.

LAN board Information

- LAN board name (factory default: Net Printer)
Set the ID of the Interface board.

TCP/IP

- Obtain an IP Address Automatically (factory default)
Automatically obtain the IP address from the DHCP server.
- Use the following IP Address
Enter IP addresses in the IP Address, Subnet Mask, and Default Gateway fields.

UPnP Setting

- UPnP (factory default: Enable)
Set the UPnP setting.

Print Settings

Configure the printing functions of the printer.

- Raw Port Number (factory default: 9100)
Set the TCP port number for RAW protocol printing.
- Timeout for print data
Set the timeout duration for the connection to the host.
- Action at Timeout
Select the action for other connections when a timeout occurs with the host. There are two selections: Close all connections and Move to next connection.

- TCP Keep Alive

Select whether the TCP Keep Alive feature is enabled or disabled.

Submit button

Enter the changes.

Reset button

Cancel the changes.

4-4-2. CONFIG>>User Account Tab

You must log in as an administrator to change the settings of the Interface board. At this screen, the administrator name and password can be changed.

The screenshot shows a web interface with three tabs: 'General', 'User Account', and 'Maintenance'. The 'User Account' tab is selected. Below the tabs is a 'Set User' section with three input fields: 'New User name' (containing 'admin'), 'New Password', and 'Confirm New Password'. Each field has a '15 letters[max.]' label to its right. At the bottom of the section are two buttons: 'Submit' and 'Reset'.


Set User

- New User name (factory default: admin)
Enter the new administrator name.
- New Password (factory default: admin)
Enter the new password.
- Confirm New Password
Enter the password again.

Warning


If you forget the new username and password, settings must be returned to the factory default settings.

4-4-3. CONFIG>>Maintenance Tab



- Save & Restart button
Save changes, and restart the Interface board.
- Restart button
Restart the Interface board without saving changes.
- Factory Default button
Return the Interface board to the factory default settings.
- Firmware Upgrade button
Upgrade the firmware of the Interface board.

Firmware upgrade



- 1) Click "Browse" and select the firmware file.
- 2) Click "Write".

Warning

After the firmware upgrade starts, do not disconnect power or transmission to the printer until the upgrade is complete.

When updating the firmware, it is necessary to obtain the correct firmware data from us.


If the firmware is not updated correctly, this interface board may not boot.

5. NetToolK


The “NetToolK” utility software runs on the Windows operating system and can be used to change the settings of the Interface board. This tool can be used with both wired and wireless LAN interface boards.

5-1. Installing the NetToolK

- 1) Acquire the file “NetToolKSetup.exe” from our website. Double click the file.
- 2) If the “User Account Control” screen appears, click “Continue.”
- 3) The screen shown on the right appears.
Click “Next.”




- 4) Enter a username and organization,
and then click “Next”.




4 NetToolK


- 5) The screen shown on the right appears.
Click “Next.”




- 6) The screen shown on the right appears.
Click “Install”.



- 7) Click “Finish” to complete installation.




- 8) The PC setting tool starts. From the “System” menu, select “Exit”.



- 9) The icon on the right is placed on the desktop of the computer. You can now start program by double clicking this icon.





5-2. Information List Window



① “System”
Select “System” – “Exit” to exit the NetToolK.

② “Tools”
Select “Tools” – “Settings” to switch the display of the LAN interface board information. When the “Show LAN board information” check box is selected, the LAN interface board operation status can be displayed as shown below.



- ③ "Help" menu
Select "Help" – "About" to display the version information of the NetToolK.

- ④ "Refresh List" button
Refresh the list of the LAN interface board. The application periodically refreshes the list, but you can refresh the list manually by clicking this button.

- ⑤ "Go to Web Page" button
Select the LAN interface board you want to configure, and then click "Configure using a web browser". The browser starts and displays the Web manager.

- ⑥ "Configure the LAN Board" button
Select the LAN interface board you want to configure, and then click "Configure the LAN Board". See 5-3 Setup Window (page 36).

- ⑦ LAN interface board list
The list displays the LAN interface boards connected to the network. The LAN interface boards connected to the same subnet are displayed.


5-3. Setup Window

You can configure the LAN interface board by selecting the LAN interface board from the list screen and clicking “Configure the LAN Board”.

To login at the login screen, enter a username and password.


Username: admin (factory default)

Password: admin: (factory default)



5-3-1. “General” Tab


Use the “General” tab to configure the LAN board name and IP address



5-3-2. “Wireless LAN” Tab


Use the “Wireless LAN” tab to configure the LAN.

(This tab is not displayed for a wired LAN interface board.)



5-3-3. "Supported Protocols" Tab

Use the "Supported Protocols" tab to enable LPR and the RAW protocol, set the printer timeout duration, enable "Priority to Ethernet", and enable UPnP.




5-3-4. "User Account" Tab

Use the "User Account" tab to change the administrator name and password.

Warning

If you forget the new username and password, settings must be returned to the factory default settings.



5-3-5. "Maintenance" Tab


Use the "Maintenance" tab to restart the LAN interface board, return the settings to the factory default settings, and update the firmware.

Warning

After the firmware upgrade starts, do not disconnect power or transmission to the printer until the upgrade is complete.



When updating the firmware, it is necessary to obtain the correct firmware data from us.

If the firmware is not updated correctly, this interface board may not boot.



4 NetToolK

Note: If the computer at which you are performing the configuration and the LAN interface board have different subnet values, a message like the one shown below appears in red letters. If this message appears, set the IP address using the “Configure the LAN Board” button before configuring the LAN interface board.



Only the server name and IP address can be configured. Configure the IP address correctly one time before configuring the wireless LAN interface board.

6. XML Print / Peripheral Device Control Function

6-1. Overview

The XML Print / Peripheral device control function are functions of this interface board to convert specific data in XML tag format to implement functions such as printing.

The peripheral device control function is a function to control a device connected to USB ports of the interface board by using data in XML tag format. (A method to control a peripheral device without using the XML function is also provided.)

See the separate documents for CITIZEN XML Print Service for details on data in XML tag format, JavaScript library to generate that data, etc.

This function can be used when the following conditions are met.

Printer supports the XML function.

This interface is connected.

The firmware version of the printer and this interface board supports XML function.

If the conditions are met, the Service Status tab is displayed in the STATUS window and the Service tab & SSL/TLS tab are displayed in the CONFIG window.

When using these functions, the URL to which the XML tag format data is sent is as follows.

If you use the URL specification method by port number, the numeric part will change depending on the port number setting.

		URL
HTTP	XML Print service	http://IP address:8080/ http://IP address/xmlprint/
	XML Device service	http://IP address:8085/ http://IP address/xmldevice/
	XML Config service	http://IP address/xmlconfig/
HTTPS	XML Print service	https://IP address/xmlprint/
	XML Device service	https://IP address/xmldevice/
	XML Config service	https://IP address/xmlconfig/

4 XML Print / Peripheral Device Control Function

6-2. CONFIG>>Service Tab

The setting items that are displayed differ depending on the type of interface board that is connected to the printer.

IFx-EFX2: All items

IFx-EFX1 / IFx-EFX3: XML Print and XML Config items only

The Media Converter items may be displayed even when the interface board is used in combination with a printer that does not meet the conditions.

General	Service	SSL/TLS	Request Print	User Account	Maintenance
Media Converter					
VCOM Convert	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable	<input type="checkbox"/> Show configuration		
HID Scanner Convert	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable	<input type="checkbox"/> Show configuration		
XML Print					
Port Number	<input type="text" value="8080"/>				
Timeout for connect	<input type="text" value="10"/>	5-60[Seconds]			
Timeout for print	<input type="text" value="60"/>	10-600[Seconds]			
XML Device Control					
Port Number	<input type="text" value="8085"/>				
Timeout for connect	<input type="text" value="10"/>	5-180[Seconds]			
Max connection	<input type="text" value="2"/>				
XML Device Control / Line Display					
Baud rate	<input type="text" value="9600"/>				
Data	<input type="text" value="8 bit"/>				
Parity	<input type="text" value="None"/>				
Stop	<input type="text" value="1 bit"/>				
Flow Control	<input type="text" value="Off"/>				
<input type="button" value="Test Device"/>					
XML Device Control / Scanner					
<input type="button" value="Test Device"/>					
XML Device Control / Speaker					
<input type="button" value="Test Device"/>					
XML Config					
Timeout for connect	<input type="text" value="10"/>	5-180[Seconds]			
<input type="button" value="Submit"/> <input type="button" value="Reset"/>					

6-2-1. Media Converter

Item	Initial value	Configurable range	Description
VCOM Convert	Disable	Enable Disable	Set Enable when using a display or scanner using OPOS without XML control.
HID Scanner Convert	Disable	Enable Disable	Set Enable when using a scanner in HID mode without XML control.
Show Configuration	Unselected	Selected Unselected	If you select this, the advanced settings for communication with the device are displayed. The initial value of each item is the value for the corresponding device so there is no need to change it.

6-2-2. XML Print

Item	Initial value	Configurable range	Description
Port Number	8080	1025 - 65535	Connection port number
Timeout for connect	10	5 - 60	Timeout time to wait for printing to start
Timeout for print	60	10 - 600	Timeout period for waiting for printer processing completion

6-2-3. XML Device Control

Configure the following general settings for XML Device Control Service.

Item	Initial value	Configurable range	Description
Port Number	8085	1025 - 65535	Connection port number
Timeout for connect	10	5 - 180	Timeout time to wait for control to start (sec.)
Max Connections	2	1 - 3	Maximum number of simultaneous connections (normally use with the initial value)

4 XML Print / Peripheral Device Control Function

6-2-4. XML Device Control / Line Display

Configure the following general settings for a display. The setting initial values are already the appropriate values for the corresponding display so do not change them in the case of normal use.

Item	Initial value	Configurable range
Baud rate	9600	2400, 4800, 9600, 19200, 38400, 57600, 115200
Data	8 bit	7 bit, 8 bit
Parity	None	None, Odd, Even
Stop	1 bit	1 bit, 2 bit
Flow Control	Off	Hardware, Xon/Xoff, Off

If you press the "Test Device" button, a text string is displayed on the display according to these settings. If a connection with the display cannot be confirmed, an alert message ("Test failed") is displayed in the browser.

6-2-5. XML Device Control / Scanner

If you press the "Test Device" button, the connection with the scanner (USB HID keyboard method) is checked. If a connection with the scanner cannot be confirmed, an alert message ("Test failed") is displayed in the browser.

6-2-6. XML Device Control / Speaker

If the "Test Device" button is pressed while a USB speaker is connected, the sound (chime) prerecorded in the interface board is played. If a connection with the USB speaker cannot be confirmed, an alert message ("Test failed") is displayed in the browser.

If you wish to use this function, submit an inquiry to us.

6-2-7. XML Config

This function allows you to set some configuration items at once. For details, please refer to "CITIZEN XML Config Service JavaScript Config SDK Programming Manual".

Item	Initial value	Configurable range	Description
Timeout for connect	10	5 - 180	Timeout period for waiting for processing to start

6-2-8. Submit / Reset Button

After changing the settings, press the "Submit" button and then press the "Save & Reboot" button in the Maintenance menu. The settings will be enabled after the board reboots.

6-3. STATUS>>Service Status Tab

System Status	Network Status	Printer Status	Service Status	Request Print
Media Converter				
Service Version:			1.0	
VCOM #1				
Status:			Disabled	
Port Number:			9200	
Type:				
VCOM #2				
Status:			Disabled	
Port Number:			9201	
Type:				
HID Scanner				
Status:			Disabled	
Port Number:			9210	
XML Print				
Service Version:			3.0	
Port Number:			8080	
XML Device Control				
Service Version:			1.2	
Port Number:			8085	
LineDisplay Status:			Offline	
Scanner Status:			Offline	
Speaker Status:			Offline	
XML Config				
Service Version:			1.0	

The settings on the Service tab, the connection state of the peripheral device, etc. are reflected here.

7. SSL/TLS function

7-1. Overview

Necessity of SSL/TLS support

Encrypted communication is necessary to prevent third parties from eavesdropping on, altering, or spoofing the communication data flowing over the network. The SSL/TLS protocol has become the standard for encrypted communication infrastructure.

The http protocol is used to send and receive web data and XML data, and https is the SSL/TLS-compatible version of it. If https is used for communication between the host and the printer, the printer must also support SSL/TLS.

Overview of SSL/TLS support

A digitally signed certificate (hereafter referred to as a signed certificate) is required for SSL/TLS encrypted communication. The server stores the signed certificate, and the client side must confirm or approve the certificate as trustworthy to enable SSL/TLS encrypted communication.

There are two types of signing certificates: those signed by a public certification authority (CA) and self-signed certificates signed by the private CA.

In the case of self-signed certificates, the client side must certify that the certificate is trustworthy so that it can communicate without warning. For this purpose, this board has a function to export a file that contains the unique information for certification.

This board also allows importing a certificate signed by a public CA for more secure communication.

Differences in procedures for preparing signed certificates between this board and a normal server

For SSL/TLS communication, you will need a signed certificate file and a private key file. The general procedure for preparing these on a normal server is as follows.

1. The applicant requesting the certificate generates a private key.
2. Applicant creates a certificate signing request (CSR) by entering the applicant's identification information and adding a signature with the applicant's private key.
3. The applicant submits the CSR to either a self-certification authority prepared by the applicant or an external public CA.
4. The signing authority generates a certificate with its own private key signature attached to the CSR and returns it to the applicant. (Depending on the submitted certification authority, the certification becomes either a self-signed certificate or a public CA signed certificate).
5. The applicant stores and places the signed certificate file and his private key file.

This board has an internal private key and self-certification authority, and if you want to use a self-signed certificate, you only need to enter the identification information in step 2 above. (For the detailed procedure, refer to 7-3-1 Creating and exporting a self-signed certificate.

On the other hand, to use a public CA signed certificate on this board, the user must perform steps 1 through 4 above, and then import the certificate file (which has signature by public CA) and the applicant's private key file to this board (as step5).

It is also possible to import self-signed a certificate prepared by the user (not generated by this board) into this board in the same way as public CA signed certificate.

Certificate Expiration

Signed certificate have expiration date and must be updated to the new expiration date before they expire. A window to update the expiration date is also provided, or you can use the XML Config function to send an XML file to the printer for updating expiration date.

Types of Certificates and Descriptions in Subsequent Chapters

The certification authority that issues the certificate and the way the certificate is handled on this board are as follows

- A. Internal certificate: A self-signed certificate generated and stored inside the printer.
- B. Local certificate: A certificate signed by a private certification authority (CA) on the local network and imported into the board.
- C. Public certificate: A certificate 子 signed by a public certification authority (CA) on the Internet and imported into the board.

The descriptions in the following chapters correspond to certificate A, B, or C as follows.

Chapter	A. Internal certificate	B. Local certificate	C. Public certificate
7-2-1	Applicable	Applicable	Applicable
7-2-2	Applicable		
7-2-3	Applicable		
7-3-1	Applicable		
7-3-2	Applicable	Applicable	
7-4-1	Applicable	Applicable	Applicable
7-4-2	Applicable		
7-4-3		Applicable	Applicable
7-4-4	Applicable	Applicable	Applicable

There are two types of local certificates: those with the same certification server and certification authority, and those with a different certification server and certification authority. The differences do not affect whether the explanations in each chapter are applicable or not, so they are not separated. However, depending on the browser you use and other factors, there may be differences between these two conditions.

7-2. CONFIG>>SSL/TLS Tab

7-2-1. SSL/TLS tab

The screenshot shows the 'SSL/TLS' configuration page. At the top, there are tabs for 'General', 'Service', 'SSL/TLS', 'Request Print', 'User Account', and 'Maintenance'. The 'SSL/TLS' tab is selected. Below the tabs, there are several sections:

- SSL/TLS Setting:** A 'Service' section with radio buttons for 'Enable' (selected) and 'Disable'.
- Certificate Setting:** A 'Server Certification' dropdown menu currently set to 'CA-Signed Certificate'.
- Self-Signed Certificate:** A section with four buttons: 'Create', 'Update', 'Export', and 'Delete'.
- CA-Signed Certificate:** A section with two file selection fields: 'CA-Signed Certificate File' and 'Private Key File', each with a 'Choose File' button and the text 'No file chosen'. Below these are 'Import' and 'Delete' buttons.

At the bottom of the page, there are 'Submit' and 'Reset' buttons.

SSL/TLS Setting

- Service
Select whether the SSL/TLS function is enabled or disabled.

Certificate Setting

- Server Certification
Select the server certificate type used for SSL/TLS communication from either Self-Signed Certificate or CA-signed certificate.

Self-Signed Certificate

- “Create” button
Move to “Create Self-Signed Certificate” page. See “7-2-2 Create Self-Signed Certificate”.
- “Update” button
Move to “Update Self-Signed Certificate” page. See “7-2-3 Update Self-Signed Certificate”.
- “Export” button
Export a certificate to install the server information to the client.
No need to reinstall for certificate renewal.
- “Delete” button
Deletes the self-signed certificate that was created.

CA-Signed Certificate

- CA-Signed Certificate File
Select the public CA signed certificate file to import.
- Private Key File
Select the private key file to import.
- “Import” button
Import the selected certificate and private key into the printer.
- “Delete” button
Delete the imported certificate and private key.

7-2-2. Create Self-Signed Certificate

Field	Value	Format/Requirement
Common Name *	192.168.1.100	
Organization Unit		
Organization *	CITIZEN SYSTEMS JAPAN	
Locate		
State		
Country *	JP	2 characters
Validity (Not Before) *	2020/04/01	YYYY/MM/DD
Validity (Not After) *	2021/04/01	YYYY/MM/DD
Internal Certification Authority		
Validity (Not Before) *	2020/04/01	YYYY/MM/DD
Validity (Not After) *	2049/12/31	YYYY/MM/DD

* mandatory field

Create Self-Signed Certificate (Items and meanings for CA-Signed Certificate are the same.)

- Issuer
 - Enter the information about the organization that operates the server (administrator).
- Common Name
 - Enter the IP address or FQDN of the print server.
- Organization Unit
 - Enter the name of the department of the operating organization.
- Organization
 - Enter the name of the operating organization.
- Locate
 - Enter the location (city, ward, town, village, etc.) of the Operator.
- State
 - Enter the location of the Operator (State/Prefecture).
- Country
 - Enter the country code where the Operator is located using two letters of the alphabet.
- Validity (Not Before) (Default: Entry Date)
 - Enter the start date of the certificate validity period.
- Validity (Not After) (Default: 1 year after the entry date)
 - Enter the end date of the certificate validity period.
- Internal Certification Authority
 - This field is for entering information about certificate renewal.
- Validity (Not Before) (Default value: Entry date)
 - Enter the start date of the period for which you wish to renew the certificate. Enter the Specify a date before the certificate validity period.
- Validity (Not After) (Default: 12/31/2049)
 - Enter the end date of the period for which you wish to renew the certificate. Specify the date after the certificate validity period.

7-2-3. Update Self-Signed Certificate

Field	Value	Format/Note
Issuer		
Common Name *	192.168.1.100	
Organization Unit		
Organization *	CITIZEN SYSTEMS JAPAN	
Locate		
State		
Country *	JP	2 characters
Validity (Not Before) *	2021/05/01	YYYY/MM/DD
Validity (Not After) *	2022/05/01	YYYY/MM/DD
Internal Certification Authority		
Validity (Not Before) *	2020/04/01	YYYY/MM/DD
Validity (Not After) *	2049/12/31	YYYY/MM/DD

Update Self-Signed Certificate


(The same applies to the items on the CA-Signed Certificate Update.)

- Issuer
Enter the information about the organization that operates the server (administrator).
- Common Name
Enter the IP address or FQDN of the print server.
- Organization Unit
Enter the name of the department of the operating organization.
- Organization
Enter the name of the operating organization.
- Locate
Enter the location (city, ward, town, village, etc.) of the Operator.
- State
Enter the location of the Operator (State/Prefecture).
- Country
Enter the country code where the Operator is located using two letters of the alphabet.
- Validity (Not Before) (Default value: Entry date)
Enter the start date of the certificate validity period within the period for which the certificate can be renewed.
- Validity (Not After) (Default: 1 year after the entry date)
Enter the end date of the certificate validity period within the period for certificate renewal.
- Internal Certification Authority
Displays information on certificate renewal.
- Validity (Not Before)
displays the start date of the period during which certificate renewal is possible.
- Validity (Not After)
displays the end date of the period for which the certificate can be renewed.


7-3. To enable SSL/TLS communication using a self-signed certificate

7-3-1. Generating and exporting self-signed certificates

1) Access the IP address of the board from your browser. 2) Select the "CONFIG" tab.



3) Enter User Name: admin, Password: admin to enter the configuration screen.



4 SSL/TLS function

4) Set a static IP and select the "Submit" button.

The screenshot shows the 'LAN board' configuration page for 'CITIZEN SYSTEMS'. The 'CONFIG' menu is active, and the 'SSL/TLS' tab is selected. The 'TCP/IP' section is expanded, showing the following settings:

- Obtain an IP Address Automatically
- Use the following IP Address
- IP Address: 192.168.1.30 (15 letters[max.])
- Subnet Mask: 255.255.255.0 (15 letters[max.])
- Default Gateway: 192.168.1.1 (15 letters[max.])

The 'UPnP Setting' section shows 'UPnP' is set to 'Enable'. The 'Print Settings' section shows 'Raw Port Number' as 9100, 'Timeout for print data' as 180 (0-65535[Seconds]), and 'Action at Timeout' set to 'Close all connections'. The 'Submit' button is circled in red.

5) Select the "SSL/TLS" tab and go to the SSL/TLS setting window.

6) Click the "Create" button to enter the self-certification windows.

The screenshot shows the 'LAN board' configuration page for 'CITIZEN SYSTEMS'. The 'CONFIG' menu is active, and the 'SSL/TLS' tab is selected. The 'SSL/TLS Setting' section is expanded, showing the following settings:

- Service: Enable Disable
- Certificate Setting: Server Certification: Self-Signed Certificate
- Self-Signed Certificate: Create, Update, Export, Delete
- CA-Signed Certificate: CA-Signed Certificate File: Choose File (No file chosen), Private Key File: Choose File (No file chosen), Import, Delete

The 'Create' button is circled in red. The 'Submit' and 'Reset' buttons are also visible at the bottom.

7) Enter a static IP in Common Name,.

For Validity, the first one is the validity period of the certificate stored on the board, and the second one is the validity period of the file to be exported. Basically, there is no need to change it.

An error will occur if the first Validity is set outside the period of the second Validity.

8) Click the "Create" button.

LAN board CITIZEN SYSTEMS

HOME | STATUS | CONFIG Logout

General Service **SSL/TLS** Request Print User Account Maintenance

Create Self-Signed Certificate

Issuer

Common Name *

Organization Unit

Organization*

Locate

State

Country * 2 characters

Validity (Not Before) * YYYY/MM/DD

Validity (Not After) * YYYY/MM/DD

Internal Certification Authority


Validity (Not Before) * YYYY/MM/DD

Validity (Not After) * YYYY/MM/DD


* mandatory field

4 SSL/TLS function


9) Press the "OK" button.




- 10) Select "Enable" for Service and CA-Signed Certificate for Server Certification in SSL/TLS Setting.
- 11) Click the "Export" button to save the self-certificate file. The file will be used for importing into your browser.
- 12) Press the "Submit" button.



13) Press "Save & Reboot".



14) Click the "Yes" button to save & reboot.




Please wait until the board reboots. The configuration changes will be reflected after the reboot.


4 SSL/TLS function

7-3-2. Example of importing a self-signed certificate in a browser (Chrome)


Chrome Settings => Privacy and security => Security => Manage certificate




Select the "Trusted Root Certification Authorities" tab and click the "Import" button.



Press "Next".




Press "Browse" and choose the self-signed certificate file that you exported in 7-3-1 and press "Next".



4 SSL/TLS function

Press "Next".



← Certificate Import Wizard

Certificate Store
Certificate stores are system areas where certificates are kept.


Windows can automatically select a certificate store, or you can specify a location for the certificate.

Automatically select the certificate store based on the type of certificate

Place all certificates in the following store

Certificate store:
Trusted Root Certification Authorities

Press "Finish"



← Certificate Import Wizard


Completing the Certificate Import Wizard

The certificate will be imported after you click Finish.

You have specified the following settings:

Certificate Store Selected by User	Trusted Root Certification Authorities
Content	Certificate
File Name	C:\CITIZEN\CitizenCertificate.crt

When a security warning appears, press Yes to complete the certificate installation, Then the printer's self-signed certificate has been registered with the "Trusted Root Certification Authority".



This will allow SSL/TLS communication between this Chrome and the printer using https without warning. The procedure is basically the same for other browsers.

Note

When using a self-signed certificate exported from this board, it is necessary to import the certificate for each browser as shown in this procedure to prevent the warning from appearing. However, if the user has prepared a self-signed certificate separately from this board, the self-signed certificate and private key can be registered as a set to this board, just like a public CA signed certificate, so that no warning will be issued without importing the certificate for each browser.

For more information, please contact us.

4 SSL/TLS function

7-4. SSL/TLS and certificate related specifications

7-4-1. SSL/TLS communication specifications

TCP/IP version	TCP/IP v4
SSL/TLS version	TLS1.2(SSL3.3)
Application protocol	HTTPS (Server Authentication)
TCP communication port	443
Supported certificate	Self-signed certificate CA signed certificate
Encryption algorithm	AES 128/256
Hash algorithm	SHA2-256, SHA1
Key Exchange Method	RSA 2048 bit

Supported cipher suite

Priority	Cipher suite
1	TLS_RSA_WITH_AES_256_CBC_SHA256
2	TLS_DHE_RSA_WITH_AES_256_CBC_SHA256
3	TLS_RSA_WITH_AES_256_CBC_SHA
4	TLS_DHE_RSA_WITH_AES_256_CBC_SHA
5	TLS_ECDHE_RSA_WITH_AES_256_CBC_SHA
6	TLS_RSA_WITH_AES_128_CBC_SHA256
7	TLS_DHE_RSA_WITH_AES_128_CBC_SHA256
8	TLS_ECDHE_RSA_WITH_AES_128_CBC_SHA256
9	TLS_RSA_WITH_AES_128_GCM_SHA256
10	TLS_DHE_RSA_WITH_AES_128_GCM_SHA256
11	TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256
12	TLS_DHE_RSA_WITH_CHACHA20_POLY1305_SHA256
13	TLS_ECDHE_RSA_WITH_CHACHA20_POLY1305_SHA256
14	TLS_RSA_WITH_AES_128_CBC_SHA
15	TLS_DHE_RSA_WITH_AES_128_CBC_SHA
16	TLS_ECDHE_RSA_WITH_AES_128_CBC_SHA

7-4-2. Self-signed certificate related specifications

By entering the necessary items on the Web Manager screen, you can issue, save, and export a self-signed certificate on this board. The initial state is without certificate information.

Self-signed certificate entry field

Field	Items	Initial value	Available characters and symbols	Max. Chars
Issuer Subject	Common Name (CN)	IP address in use	Alphanumeric, Space, "-" (Hyphen), "." (Dot) (Inputs other than IP addresses are allowed.)	64 chars
	Organization Unit (OU)	(Blank)	Alphanumeric, Space, "," (Comma), "+" (Plus),	64 chars
	Organization (O)	CITIZEN SYSTEMS JAPAN	"-" (Hyphen), "." (Dot), "/" (Slash), "_" (Underscore),	64 chars
	Locate (L)	(Blank)	"(" (Bracket L),)" (Bracket R)	128 chars
	State (S)	(Blank)		128 chars
	Country (C)	JP	Alphanumeric	2 chars
Validity (Not After)		2049/12/31 or 1 year after "Create"	YYYY/MM/DD (2020/01/01 ~ 2049/12/31)	
Validity (Not Before)		2020/01/01 or the time of "Create"	YYYY/MM/DD (2020/01/01 ~ 2049/12/31)	

The other items set in the certificate creation are entered as shown in the table below. No changes can be made by the user.

Self-signed certificate fixed fields

Field	Items	Fixed value
Certificate Subject Alt Name	DNS Name	Common name (CN)
	IP Address	Common name (CN) if common name is IP address.
Certificate Key Usage		Non-repudiation, Digital Signature, Key Encipherment (a0)
Extended Key Usage		TLS Web Server Authentication (1.3.6.1.5.5.7.3.1)
		TLS Web Client Authentication (1.3.6.1.5.5.7.3.2)
Certificate Basic Constraint	Subject Type	End Entity
	Path Length	None
	Constraint	

4 SSL/TLS function

Specification for exporting a certificate file signed by a internal certifying authority.

Encoding type	Base64
File extension	.crt
Version	V3
Key Exchange Method	RSA 2048 bit
Signature algorithm	SHA2-256 with RSA

7-4-3. CA signed certificate related specifications

The specifications of CA signed certificate that can be imported and used are as follows.

Please make sure that the certificate and private key are paired before importing.

CA signed certificate	“.pem” format / “.der” format
Private key	“.key” format (Password protection not supported)
Encryption algorithm	AES 128/256
Hash algorithm	SHA2-256, SHA1
Key Exchange Method	RSA 2048 bit

7-4-4. Handling of saved certificates when restoring factory settings/updating firmware

When the Factory Default process in the CONFIG>>Maintenance Tab is executed, each setting value will be set to the default value and the registered certificate will be deleted; when the Firmware Upgrade process is executed, each setting value and the registered certificate will be retained.


8. Request Print function

8-1. Overview

The request printing function is required to realize printing from the Web server to the printer.

The general procedure is as follows.

This board periodically sends to the Web server a print data request. On the other hand, the server needs to respond to the print data request when the request comes in, and if the print data exists on the server, server needs includes the print data in the response



This chapter describes the settings for request printing on this board side.

The request, response, and print data are in XML format. For details on the messages structure etc., please refer to the Request Print Programmer Manual prepared separately.

A sample kit that can be installed on a Web server for demonstration is also available, and the manual explains how to install it.

This function is available when the following conditions are met

- The printer must be a model that supports the XML function.

- IFx-EFX2 with firmware version 2.30 or higher is connected to the printer.

- The printer's firmware must support the connection to the IFx-EFX2.

When these conditions are met, the Request Print tab will appear on the STATUS window and the Request Print tab will appear on the CONFIG window in the Web Manager.

4 Request Print function

8-2. CONFIG>>Request Print Tab

General	Service	SSL/TLS	Request Print	User Account	Maintenance
Request Print Settings					
Request Print	<input type="radio"/> Enable <input checked="" type="radio"/> Disable				
URL	<input type="text" value="http://example.com/test.php"/>	2048 letters[max.]			
Via Proxy Server	<input type="radio"/> Enable <input checked="" type="radio"/> Disable				
Proxy Address	<input type="text" value="192.168.100.190"/>	15 letters[max.]			
Proxy Port	<input type="text" value="8080"/>	1025-65535			
Interval	<input type="text" value="10"/>	1-600[Seconds]			
ID	<input type="text" value="00-11-E5-07-4A-6A"/>	64 letters[max.]			
DNS					
DNS1	<input type="text" value="8.8.8.8"/>	15 letters[max.]			
DNS2	<input type="text" value="8.8.4.4"/>	15 letters[max.]			
Basic Authorization Settings					
Basic Authorization	<input type="radio"/> Enable <input checked="" type="radio"/> Disable				
User	<input type="text" value="admin"/>				
Password	<input type="password" value="****"/>				
Warning print for failed Requests					
Number of allowed failure before warning	<input type="text" value="0"/>	0-100(Set 0 to disable this function.)			
Beep for warning	<input type="radio"/> Enable <input checked="" type="radio"/> Disable				
<input type="button" value="Submit"/> <input type="button" value="Reset"/>					

Request Print Settings

- Request Print (Default: Disable)
Set whether to enable the request printing function.
- URL
Enter the server URL of the request.
- Via Proxy Server (Default: Disable)
Enables or disables the proxy setting.
- Proxy Address
Enter the IP address of the proxy server.
- Proxy Port
Enter the port of the proxy server.
- Interval
Enter the interval at which you want to make requests to the server.
- ID (Default: Mac address of this interface board)
Enter the individual identification code to be sent upon request.
- DNS
Enter IP addresses of "preferred DNS" and "alternate DNS" to be used when making requests.

Basic Authorization Settings

If the server to which printer is communicating requires Basic authentication, it can pass the authentication and communicate with the server by this function.

- Basic Authorization (Default: Disable)
Sets whether to send Basic authentication credentials to the request destination server.
- User
Enter the user name to be used for basic authentication.

- Password
Enter the password to be used for Basic Authentication.

Warning print for failed Requests

If communication with the server for the request print fails, this board can notify you of it by printing or beeping.

- Number of allowed failure before warning (Default: 0)
Enter the number of consecutive failures before an alarm printout is executed.
If 0 is entered, the alarm printing function is disabled.
- Beep for warning (Default: Disable)
Sets whether to enable the buzzer function for alarm printing.

8-3. STATUS>>Request Print Tab

System Status	Network Status	Printer Status	Service Status	Request Print
Request Print Settings				
Service Version:	1.0			
Status:	Disable			
URL:	http://example.com/test.php			
Proxy				
Proxy Address:				
Proxy Port:				
Interval:	10 sec			
ID:	00-11-E5-07-4A-6A			
DNS				
DNS1:	8.8.8.8			
DNS2:	8.8.4.4			
Basic Authorization Settings				
Status:	Disable			
User:	admin			
Warning print for failed Requests				
Number of allowed failure before warning:	0			
Beep for warning:	Disable			

The settings on the Request Print tab and the connection status of peripheral devices are shown here.

8-4. Printing system log

If Request Print did not work as expected, you may be able to check the situation by checking the system log of this board.

Please refer to Chapter 5 "Useful Functions for Request Print" in the "Programmer's Manual for "Request Print" for a description of system log printing.